
Manual Emergency Operation SCHUBERT SALZER

for Type 7010, 7030, 7031, 7070, 7080




Additional manual operation:

(for normally closed version)

The valve can be opened manually by using the locking handle.

| Actuator | L | G | Р | H1 | H2 |
|----------------------------------------|----|--------|----|----|----|
| 50 | 48 | G 1/8" | 32 | 39 | 55 |
| 80 | 60 | G 1/4" | 40 | 57 | 86 |
| 125 60 G 1/4" 40 50 79 | | | | | 79 |
| In order number system designated as 4 | | | | | |




Stroke limitation:

(for normally closed version)

The maximum stroke can be limited with the help of an additional travel stop at the elongated piston rod.

| Actuator | D | | G | Н | Stroke |
|----------------------------------------|-----|------|--------|------|--------|
| 50 | 62 | 34,5 | G 1/8" | 67,5 | 16 |
| 80 | 98 | 55 | G 1/4" | 69 | 30 |
| 125 | 144 | 78 | G 1/4" | 62 | 30 |
| In order number system desginated as 5 | | | | | |



Manual emergency operation and stroke limitation:


(for normally open version)

Using the set screw with packing you can limit the stroke or close valve in emergency.

| Actuator | G | D | Hmax. | |
|----------------------------------------|--------|----|-------|------|
| 50 | G 1/8" | 62 | 95 | 40,5 |
| 80 | G 1/4" | 98 | 95 | 61 |
| 125 G 1/4" 144 95 84 | | | | 84 |
| In order number system desginated as 3 | | | | |








| Actuator | В | С | Hmax | No. of springs |
|----------------------------------------|-----|-----|------|----------------|
| 125 | 165 | 125 | 115 | up to 6 |
| 125 | 165 | 200 | 125 | up to 8 |
| 250 222 200 120 - | | | | |
| In order number system designated as 1 | | | | |

Additional Manual Operation



for Type 8021





| Antrieb | В | |
|---------|-----|--|
| D125 | 165 | |
| D125 | 165 | |
| D250 | 222 | |

In order number systems designated as 1